

# DDMWorks



Automotive Performance Specialists

## Fender Well Trim Kits



The DDMWorks Fender well trim kit uses a weather resistance edge grip with foam rubber closed-cell bulb. The gripping portion has individual aluminum clips which provides a permanent and secure grip, keeping dirt and grime from your engine bay.

Installation time of the trim kit varies, but can usually be installed in under 30 minutes.

If you have any questions during installation you can call us at (864) 907-6004 or email us at [Tech@ddmworks.com](mailto:Tech@ddmworks.com).



---

### PACKING LIST

Item	Qty
20 inches of bulb molding	2

### TOOLS NEEDED

Heavy duty scissors, shears or tin snips

# DDMWorks



119-A Hwy 183  
Piedmont, SC 29673

**Tech Support**  
(864) 907-6004  
[Tech@DDMWorks.com](mailto:Tech@DDMWorks.com)

# DDMWorks



Automotive Performance Specialists

## Fender Trim Kits



Start with a clean surface Prima Nero is suggested

Start with a clean surface, Prima's Nero is suggested but any cleaner will do.

1. Begin on either edge of your fender well. Using your thumb and forefinger begin pressing the clipping edge of the molding along the outside edge of your fender well.
2. Continue this process the length of the fender well, you may need to use both hands.
3. Trim any excess molding for a clean fit.
4. Repeat on the other side.
5. Enjoy a cleaner engine bay!



# DDMWorks



Automotive Performance Specialists

119-A Hwy 183  
Piedmont, SC 29673

**Tech Support**

(864) 907-6004

Tech@DDMWorks.com